











ATLAS Psací stůl/Písací stôl


Montážní/Montážny návod



Seznam dílů/Zoznam dielov

A09  48x	A16  47x 10x	A29  14x	A23  6x	A24  2x
A21  2x	A22  4x	A60  2x		







A09




x12




A09




A09



A09









A09



x10









A09



x16





A23



x4

A22








x2

A60




x2




A22



A60





A23



A09



x4





11

10

12

A09





A23



x2

A22



x2

A24



x2

A21





x2

A29



x8



A24



A21



1

2

11


3

A22




11

A23



A29







A29



x4



Dovozce/Dovozca:
SCONTO Nábytek, s.r.o.,
Jeremiášova 947/16, Praha
5/SCONTO Nábytok s.r.o.,
Nová 10/8144, Trnava