





NÁVOD NA MONTÁŽ CT-761




1















2



3



A x 1 	B x 9 	C x 7 
D x 9 	E x 5 	F x 5 
G x 1 	H x 5 	I x 9 
J x 1 	K x 1 	L x 4 
M x 1 