












# MONTÁŽNÍ/MONTÁŽNY NÁVOD ELIGIA




















- (GB) Assembly instructions
- (DE) Montageanleitung
- (FR) Notice de montage
- (NL) Handleiding voor de montage
- (IT) Istruzioni di montaggio
- (HU) Szerelési útmutató
- (ES) Instrucciones de montaje
- (PL) Instrukcja montażu
- (CZ) Montážní návod
- (SK) Návod na montáž
- (HR) Montaže
- (TR) Montaj talimat
- (RO) Instrucțiuni de montaj









G139.0128/148.P61









B3	32	1	1795	450	16
B1	24	2	1795	450	16
T1	12	3	526	450	16
M1	48	4	498	367	16
262.12.859	12	5	777	364	16
S04	52	6	477	356	16
M25	8	7	777	30	16
J24	14	8	1786	517	3
W1	8	9	773	154	15
433.06.604A	1	10	1749	30	16
433.06.614A	1	11	390	30	16
MG139.0128/148. P61	4	12	508	491	16
T2	6	13	789	183	16
433.06.602A	1	14	350	100	16
		15	737	81	16
		16	350	60	16
		17	748	354	3
		18	789	160	16
		19	300	100	16
		20	737	81	16
		21	300	60	16
		22	748	304	3
		23	789	197	4
G4	20				
311.04.004	4				
311.71.510	4				

	B3		T2
	B1		311.04.004
	T1		311.71.510
	M1		282.20.715
	262.12.859		
	S04		
	433.06.604A 433.06.614A		
			M25
	G139.0128/148.P61		
	W1		S4

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Servizio • Usluga •		
Name • Nom • Nome • Naam • Nazwa Jméno • Názov • Név • Denumire Nombre • Ime • Isim	COMO	 shop • geschäft • boutique • sklep • winkel • negozio • bolt • tienda • obchod • dučan • mađaza • magazin
Nr. • No. • N° • říčísł • Ć • Sz • Ne	47 07 MM 37	
Typ • Type • Tip • Tipus • Tipo		
 		  

0 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170 180 190 200





MG020R.0064.100.P61 x 2














S4 x 4




M4X10








J11 x 2





Lichtleiste



DEKOR

