













MONTÁŽNÍ/MONTÁŽNY NÁVOD ELIGIA







- (GB) Assembly instructions
- (DE) Montageanleitung
- (FR) Notice de montage
- (NL) Handleiding voor de montage
- (IT) Istruzioni di montaggio
- (HU) Szerelési útmutató
- (ES) Instrucciones de montaje
- (PL) Instrukcja montażu
- (CZ) Montážní návod
- (SK) Návod na montáž
- (HR) Montaže
- (TR) Montaj talimat
- (RO) Instrucțiuni de montaj













G139.0128/148.P61





23












MG020R.0064.100.P61 x 6	
S4 x 4	
M16 x 10 4x16mm	
J11 x 2	





Lichtleiste



DEKOR

