



A (1 PC) 	B (1 PC) 	C (2 PCS) 	D (1 PC) 	E (2 PCS) 	F (4 PCS)
G (4 PCS) 	H (1 PC) (WITH LABEL 1) Se štítkem/so štítkom 1	I (1 PC) (WITH LABEL 2) Se štítkem/so štítkom 2	J (6 PCS) (WITH LABEL 3) Se štítkem/so štítkom 3	K (1 PC) (WITH LABEL 4) 	L (2 PCS) (WITH LABEL 5) Se štítkem/so štítkom 5
M (2 PCS) (WITH LABEL 6) Se štítkem/so štítkom 6	N (2 PCS) (WITH LABEL 7) 	O (7 PCS) (WITH LABEL 8) Se štítkem/so štítkom 8	P (4 PCS) (WITH LABEL 9) Se štítkem/so štítkom 9	Q (28 PCS) 	

1 JCBC M6 X 40mm(2 PCS) R 	2 JCBB M8 x 20 mm (8pcs) S 	3 ALLEN KEY M4 X 65mm (1 PC) Imbus 	4 ALLEN KEY M5 X 70mm (1 PC) Imbus 	5 CSK M3.5 x 16mm (60 PCS) T
6 CSK M4 x 25mm (8 PCS) U 	7 CSK M4 x 32mm (36 PCS) V 	8 CSK M4 x 50mm (32 PCS) W 	9 ROLLER (14 PCS) X Kolečko/koliesko 	10 WOOD DOWEL 20MM (8 PCS) Y Dřevěný kolík/drevený kolík
11 Power Nail 6/8 (24 PCS) Z Hřebík/klinec 	12 Adjuster 35mm (2 PCS) Z₁ Nastavovač 	13 (6 PCS) Z₂ 	14 (14 PCS) Z₃ 	15 (28 PCS) Z₄


1




2




3




4




5




6




7




8




9




10




11



12



13



Upozornenie: Zabraňte
vysunutiu zásuvky príliš ďaleko,
aby nedošlo k jej vypadnutiu.
Montáž zarážky zásuvky je
voliteľná.

Upozornění: Zabraňte vysunutí zásuvky příliš
daleko, aby nedošlo k jejímu vypadnutí. Montáž
zarážky zásuvky je volitelná.